


How XRF Analysis Works



- 1 X-rays are produced by the analyzer and pointed at a sample surface.
- 2 The energy causes inner-shell electrons to be ejected.
- 3 Outer-shell electrons fill the vacancies left by the ejected electrons and fluorescent x-rays are emitted.
- 4 The fluorescent x-rays enter the detector and send electronic pulses to the preamp.
- 5 The preamp amplifies the signals and sends them to the Digital Signal Processor (DSP).
- 6 The DSP collects and digitizes the x-ray events and sends the spectral data to the main CPU for processing.
- 7 The CPU analyzes the spectral data to produce detailed composition analysis.
- 8 Composition data and other grade or value identification are displayed and stored in memory for later recall or download to an external PC.

For more detailed information on how XRF works, visit
www.thermoscientific.com/portableid

Americas

Boston, MA
 +1 978 642 1132
niton@thermofisher.com

Europe, Middle East, Africa

Munich, Germany
 +49 89 3681 380
niton.eur@thermofisher.com

India

Mumbai, India
 +91 22 6680 3800
ininfo@thermofisher.com

Asia Pacific

New Territories, Hong Kong
 +852 2885 4613
niton.asia@thermofisher.com

The Right Analyzer for Your Application



Metal and Alloy Analysis

- Instant, positive grade identification
- Superior detection limits for tramp/trace elements
- Excellent light element performance for sorting Al, Ti, and bronze alloys



Toys and Consumer Goods

- Screen child-accessible products for regulatory compliance
- Rapid results to facilitate timely product shipments
- Thermo Scientific TestAll technology automatically selects the correct analytical mode



RoHS-WEEE Compliance/Halogen-free

- Total Pb, Cd, Hg, Cr, and Br quantified in seconds
- Pass/fail designations provided, with visual identification of out-of-spec elements
- Ideal for high-reliability systems, finished goods, and packaging



Mining Exploration and Geochemical Analysis

- Rapid survey of soil and outcrops to identify potential drill targets
- Direct screening of core and cuttings for rapid decision making on the drill rig
- High sample throughput and increased sample density over traditional lab methods



Environmental Analysis

- Rapid identification of contaminants with analytical range from Mg through U
- Lower detection limits reduce reliance on fixed-site laboratories
- GPS integration for elemental mapping with GIS systems

Thermo

SCIENTIFIC

A Thermo Fisher Scientific Brand

www.thermoscientific.com/portableid

© 2015 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific and its subsidiaries. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.